

Universal 50-Gallon Wheeled Spill Kit #SPKU-CAN-WD - Absorbs up to 45.9 Gallons



Roll your kit right to universal spills up to 45.9 gallons

- Kit contains everything you need to respond to a spill of oils, coolants, water or solvents
- Prepacked container provides easy access to contents
- Includes socks to stop spreading spills, mats and pillows to absorb liquids and safety equipment like goggles, gloves and coveralls
- Bold "Spill Kit" lettering for quick identification
- Bright yellow 50-gallon overpack with wheels to roll to the spill
- Hinged lid provides easy access
- Temporary disposal bags for easier cleanup
- Tamperproof seal helps prevent pilfering of spill response supplies

SPKU-CAN-WD Specifications

Dimensions:	23.5" W x 29" L x 36.75" H
Shipping	23.5" W x 29" L x 36.75" H
Dimensions:	
Sold as:	1 per package
Absorbency:	Up to 45.9 gal. per package
Weight:	69.25 lbs.
# per Pallet:	4
Incinerable:	No
Ship Class:	175
Includes:	100 - 15" x 19" Gray Universal HeavyWeight Defender Pads (GPB100H) 6 - 3" X 4' Gray Universal Sorbent Socks (GSO430) 4 - 3" x 12' Gray Universal Sorbent Socks (GSO1210) 1 - Emergency Response GuideBook (A-EGB) 4 - 30" X 60" Yellow Disposal Bags & Ties (A-DISP BAG) 2 - Pair Nitrile Gloves (A-GLV-NIT) 2 - Safety Goggles (A-GOG) 2 - Coveralls (A-TYVEK-L) 1 - 29" X 23.5" X 36.75: Yellow 50-Gallon Wheeled Container (A50CAN-WD) 1 - 3" x 5" Vinyl Spill Kit Label (A-KIT LABEL) 6 - 6" x 2" TamperProof Seals (A-SEAL) 3 - 28oz Shaker SuperSorb (SS1) 4 - 25/pkg Wipers (WPR500-1)

Metric Equivalent Specifications

Dimensions:	60cm W x 74cm L x 93cm H
Shipping	60cm W x 74cm L x 93cm H
Dimensions:	
Absorbency:	Up to 173.7 L per package
Weight:	31.4 kg



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com

SPKU-CAN-WD Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)